HEATSTRIP · ACCESSORY SHEET

Perpendicular wall bracket

An offset bracket to mount the radiant heater from the wall and direct heat towards an area perpendicular to the façade.



Reference	THHAC-028
Mounting type	Wall mounting, perpendicular to the wall
Design family	THH Classic series
Elegance family	Standard versions
Function	Heater projection from the wall

Compatibility

Design Classic 1500 / 2400 / 3200 W and Elegance 1800 / 2400 / 3600 W

HEATSTRIP · THHAC-028

Preparing and using this accessory

Position the mounting bracket

The perpendicular bracket projects from the wall for the Design Classic and Elegance versions listed here. Select anchors to allow for the total weight and projection.

Direct the radiant heat

Keep the panel directed towards the places to be heated. Adjust its direction using the parts intended for this mounting arrangement, then lock the connections.

Check the mounting

Check the structural anchors, fastenings and clearances specified in the heater manual. Keep the cable away from hot surfaces and passageways.

Maintenance

Before making any adjustment, disconnect the heater's power supply and allow it to cool. Clean the brackets with a soft cloth and check the mechanical connections at regular intervals.

YOUR RADIANT HEATER CONTACT

+33 (0)4 23 15 02 48
radiant-heater.com/contact
Accessory reference: THHAC-028.